

Version 4.2.94.8882

1. Fixed not to receive the push notification in LILINViewer.
2. Fixed the bypass logon issue when switching from on to off in the Web UI.

Version 4.2.94.7323 (2019/02/20) for PZD6422

1. Fixed wrong image resolution format sent to FTP automatically.
2. Fixed automatic tracking no action in PTZ schedule.
3. Fixed Live focus is not clear after clearing all preset points and pressing the Home button.
4. Fixed PZD6422 one day after the automatic tracking started, cannot track again and cannot be controlled. It needs to be restarted to be normal.
5. UPNP is changed to off in default.
6. Fixed cannot save Smart H.264 circle selection range settings.
7. When the PZD6422 is not set to any set value, the lens should not be facing backwards (out of line position) after restarting.
8. Fixed Motion does not trigger when in Home position and execute zoom in and zoom out back to home position.
9. Fixed the vertical flip of the PZD6422 model. After turning on, the control direction (up and down) actions are reversed.
10. Fixed PZD6422 model, Live page PTZ setting option could not be expanded.
11. Fixed when clear all preset points, and press Home button will not return to (0 degrees, 30 degrees) coordinates.
12. Fixed the position of 180 degrees horizontally flipping is different. PZD does not support 180 degrees function.
13. Fixed when in automatic tracking, automatic correct occurs, will stop the auto tracking and the automatically corrected OSD will not disappear.
14. Fixed lens initialization no reaction when in Autopan.
15. Fixed PTZ when in AUTOPAN, under the /control? stop=1 command, cannot stop AUTOPAN.
16. After the user finishes editing the Motion or IVS line for the first time, the alarm is not responding. You must go to the home page to open the HOME position option to use the alarm function. The default is to change the Home Position to On).
17. Fixed camera crashes when the Onvif packet was incomplete.
18. Fixed the problem that the network information is not restored to the default value when the hardware default button is pressed during the boot process until the hardware default is started.
19. When the IVS function is turned on, the Auto Tracking option will be turned off.
20. Add Auto Tracking option in PTZ schedule.
21. Fixed when HDR mode is in completely dark, will not switch to night mode issue.
22. Fixed PZD6422 model with ClickToCenter function.
23. Fixed the page, modify HTTP PORT only save the configuration file but no reboot causes the new PORT to fail.
24. Streaming 4 does not display the words SD and SAMBA, which will affect the tracking function when displayed.
25. Fixed PZD6422 model inaccurate return mode time.
26. Added when in Auto tracking upper left OSD displays "AUTO TRACKING MODE".
27. Fixed Milestone unable to control PTZ issues.

For technical support information, please contact:

LILIN ZenDesk at <http://lilin.zendesk.com>.

For sales information, please contact:

Michelle, International Sales Director, at
Email: mma@meritlilin.com.tw.

Merit LILIN Enterprise Co., LTD.
No.20, Wu-Gong 6th Rd., New Taipei Industrial Park, Wu-Gu Dist.,

New Taipei City 248, Taiwan (R.O.C.)
TEL: 886-2-2298-8988 FAX: 886-2-2298-9077
www.meritlin.com